



Superactive LED Infinity Tunnel

Instruction Manual

For optimal results, please read and follow
instructions carefully
Please keep for future reference



WARNING:
CHOKING HAZARD – Small Parts
Not suitable for children under 3 years.



3+ years

experia
innovation in every sense

Congratulations on the purchase of a Superactive LED Infinity Tunnel!

The LED Infinity Tunnel has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of switching learning and fun!

The LED Infinity Tunnel offers endless opportunities to develop numerous skills including colour recognition, cause and effect, and many more!

Please ensure you read and follow these Instructions carefully before installing or operating the unit. Please keep this manual for future reference.

Heed all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

- Ergonomic design
- Completely silent
- Latest LED technology
- No lamp change – LED
- Cool running
- Hundreds of shades of colours
- Low Voltage – transformer supplied
- Easy upgrade/maintenance
- Durable
- Easy to use
- 3 Year manufacturers guarantee (Collect and Return)
- 8 switch controller

Pack contents

1 x Superactive LED Infinity Tunnel
1 x Low Voltage Transformer
1 x Controller
4 x AA 1.5v Batteries

Please note: Only use the transformer supplied. Use of a different transformer may result in damage to the product and void the warranty. For warranty information please see separate warranty card supplied.

Getting Started

1. Place the Superactive LED Infinity Tunnel on a flat solid floor or mount securely on a wall.
2. Connect the round XLR connector (silver connector) from the Low Voltage transformer to the socket on the side of the unit.



3. Connect the standard mains plug to a mains outlet.
4. The Infinity Tunnel will now illuminate and will scroll through the many colours.
5. Now it's ready to use.
6. Insert the batteries into the 8 way controller and you are now ready to interact with the infinity tunnel by pressing any button to change the LED colours.

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth. A non abrasive cleaning agent may be used for stubborn stains. Ensure no liquid enters the base of the unit.

The unit has been designed for use by people with special needs, however this does NOT mean it is unbreakable. You must ensure the unit is not hit with anything and that no one pulls or pushes the unit.

For best results remove the batteries from the switch controller if it is not being used for a prolonged period.

Troubleshooting

Q. The unit doesn't work.

A1. Is it switched on? If so,

A2. Has the unit scrolled through its colours? If so,

A3. Have you checked the batteries in the switch controller? If so,

A4. Please contact us for further assistance.

Contact Details

For USA please email support@experia-usa.com

For Canada please email support@experia-canada.com

For UK and rest of the world email support@experia-innovations.co.uk

Telephone: 0044 (0) 845 644 0977.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

QUESTIONS & IDEAS?

If you have an idea on how to improve this product or want to see your product idea realised, please email: ideas@experia-innovations.co.uk.

All ideas are presented to our OT, technical and finance department and if all procedures are passed we will contact you to discuss your idea further.

We can't promise to develop every product but if it's a great idea, we'll try!

Manufactured proudly in the UK by:

Experia

Acorn Phase III, High Street, Grimethorpe, South Yorkshire, UK, S72 7BD



© Copyright 2015 Experia All rights reserved Experia. Experia is a registered trademark.