



multisensory room



MILE room



sensory pool



soft play



sensory bathroom



interactive floor & walls



IRiS Soundswitch Wireless Charging

01 00 05 1



Product Manual

experia
multisensory for everyone

Experia
Acorn Phase 3, High Street
Barnsley, South Yorkshire
S72 7BD, United Kingdom

T 0800 612 6077
E info@experia-innovations.co.uk
W www.experia-innovations.co.uk

Congratulations on the purchase of your IRiS Soundswitch.

The IRiS Soundswitch has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of switching learning and fun!

The IRiS Soundswitch controls any IRiS Listener with the sound of your voice.

Use of the IRiS Soundswitch encourages vocalisation skills and general noise making.

Extremely sensitive the IRiS Soundswitch has four switching modes: momentary, locked, scrolling and sound responsive. Powered by Experia's in built wireless Qi Charging, never replace a battery again!

Can operate from a distance of up to 30m.

Please ensure you have an IRiS Listener to be controlled with this product.

The IRiS Soundswitch is an IRiS Talker and can control any number of IRiS Listeners.

Put simply, it is operated by making a sound.

Please ensure you read and follow these Instructions carefully before installing or operating the unit. Please keep this manual for future reference.

Heed all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

- IRiS Wirefree Compatible
- Ergonomic Design
- Integral Microphone
- Adjustable Sensitivity
- 3.5mm External Microphone Input
- 4 modes of operation
- Rechargeable Battery
- Wireless recharging of the battery
- Durable & easy to use
- 3 Year Manufacturers Guarantee



Pack contents

- 1 x Soundswitch
- 1 x USB Cable
- 1x Wireless Charging Pad
- 1 x Power Supply
- 1 x Product Manual

Unpacking your Soundswitch

- Check packaging for signs of damage before opening.
- Do not use sharp objects during unpacking.
- Check the parts received against the Pack Contents.
- Read the product manual before use.

Getting Started

1. Switch on the unit – the switch is on the front of the unit – the LED's on the front of the unit flash.
2. Put the unit into 'sound responsive' mode by press the red Mode Select button until the blue LED next to the words 'sound responsive' flashes.
3. Decide which IRiS Listeners you want to control and pair the unit to them – see 'Pairing to IRiS Listeners' section.
4. Now it's ready to use, simply make a sound.
5. If the IRiS Listener changes colour without a sound being made, adjust the sensitivity.
6. For the unit to be fully operational it needs to be recharged every night.

Charging your Soundswitch

Although your Soundswitch will have been charged before shipment it may require recharging before use.

Simply plug the power supply into a standard mains outlet, connect the USB lead to the power supply, connect the USB lead to the charging pad and switch on the mains supply.



Now position the Soundswitch onto the charger.

When it is in the correct position you'll hear a "beep" and the charger LED on the Soundswitch will light up.

The charging LED on the charging pad will also have changed colour.



Operating Instructions

The IRiS Soundswitch operates IRiS Listeners when triggered by a sound input. The operating modes are explained below. The sensitivity of the Soundswitch is adjustable with the black dial on the front. Also on the front is a 3.5mm jack socket which allows the Soundswitch to be used with an external microphone.

Switching Modes

The unit features 4 switching modes. To put the unit into a different mode simply press the Mode Select button once. Each time the button is pressed the LED next to the current mode will illuminate.

Momentary – When a sound is detected, any IRiS Listener paired to the unit illuminates and begins changing colour every 2 seconds. When no sound is detected the light extinguishes.

Locked – as above except that when no sound is heard the Listener stops changing colour but does not extinguish.

Scrolling - IRiS Listeners paired to the unit start slowly changing colour. When a sound is detected the IRiS Listeners stop on the colour that is illuminated at that point. If you make a sound constantly the IRiS Listeners will continue to stay on that colour. When a sound is not detected the IRiS Listeners will begin changing colour again. Basically if you keep silent the IRiS Listeners paired to the IRiS Soundswitch will scroll through the colours but stop on a colour when sound is detected.

Sound Responsive – Similar to a sound to light mode, an IRiS Listener will change colour whenever a sound is heard.

Each time the unit detects a sound the LED next to the mode the unit is currently in will illuminate.

Pairing your Soundswitch with IRiS Listeners

To use your IRiS Soundswitch you will need to pair it to your IRiS Listeners

This procedure is split into 2 sections, one for those who do not have an IRiS Master Pairer and for those who do.

Without a IRiS Master Pairer

Every IRiS Listener has a button on it called a pairing button. To get the IRiS Soundswitch to work with a product, first turn on the IRiS Soundswitch, put the unit into 'sound responsive' mode then find the pairing button on the product and press it. You then need to make a sound, activating the IRiS Soundswitch within 5 seconds. The IRiS Listener will now change colour every time you make a sound if correctly paired.

With a IRiS Master Pairer

To get the IRiS Soundswitch to work with a product, first turn on the IRiS Soundswitch, put the unit into 'sound responsive' mode then decide which unit you want to control and find its pairing button on the IRiS Master Pairer and press it. You then need to make a sound, activating the IRiS Soundswitch within 5 seconds. The IRiS Listener will now change colour every time you make a sound if correctly paired.

Troubleshooting

Q1. The unit doesn't work.

A1. Has the battery been recharged? If so,

A2. Have you followed the instructions on how to pair IRiS Listeners and Talkers? If so,

A3. Have you followed the instructions for the Listeners you're trying to use with the Soundswitch?

If so please contact our support team, preferably via email, see our contact details on the next page.

CAUTION:

The wireless charging IRiS Soundswitch uses the latest lithium polymer batteries. There are no user serviceable parts and no attempt should be made to change the internal battery.

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth.

A non abrasive cleaning agent may be used for stubborn stains. Ensure no liquid enters the unit.

The unit has been designed for use by people with special needs however this does NOT mean it is unbreakable. You must ensure the unit is not dropped, thrown, stood upon, immersed in water, etc.

Guarantee

All products manufactured by ourselves are backed with a three year guarantee.

All other items carry a manufacturers 1 year guarantee.

All guarantees are collect and return.

If your product needs to be returned to our factory we will arrange collection of the item and return it to you when repaired, all we ask is you pack the product securely.

If in the unlikely event that a product purchased from us develops a fault please contact us on

Freephone 0800 612 6077 or [email us](#) and our technical team will assist

Experia Registered Office:

**Acorn Phase 3
High Street
Grimethorpe
S72 7BD**

If you have any questions or need information about any of our products and services please call us on

Freephone 0800 612 6077

If you would like a FREE Sensory Brochure you can request one by telephone or visiting our website.

For more information on Experia Free 3D Room Designs or to schedule an onsite visit from our sales team then please request a visit by telephone, email or by using the form on our website.

Support Contact Details

For USA please email support@experia-usa.com

For Canada please email support@experia-canada.com

For UK and rest of the world email support@experia-innovations.co.uk

Telephone: 0044 (0) 800 612 6077.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

Manufactured in the UK by:

Experia, Acorn Phase III, High Street, Grimethorpe, Barnsley, South Yorkshire, S72 7BD



© Copyright 2015 Experia All rights reserved Experia. Experia is a registered trademark