

M Clayton
15/01/2019
V1.0
010018

PREPARED
DATE
VER NO.
PRODUCT CODE



Instruction Manual

For

IRiS Ripple Light



experia
multisensory for everyone

Experia
Acorn Phase 3, High Street
Barnsley, South Yorkshire
S72 7BD, United Kingdom

T 0800 612 6077
Einfo@experia-innovations.co.uk
Wwww.experia-innovations.co.uk

Instruction Manual

Congratulations on the purchase of your IRiS Ripple Light!

The IRiS Ripple Light has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of switching learning and fun!

The IRiS Ripple Light offers endless opportunities to develop numerous skills including colour recognition, cause and effect, and many more.

The IRiS Ripple Light is an IRiS Listener and can be controlled by any IRiS Talkers.

Please ensure you read this Instruction Manual in full before operating the unit.

Heed all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

- IRiS Wirefree Compatible
- Small, lightweight, Design
- Silent Running
- LED, never have to change a lamp
- Unique Effect
- Easy to use
- 3 Year Manufacturers Guarantee (Return to base)

Box Contents

IRiS DMX Control Box

Ripple Light

'Y' IEC cable

3 pin 3.5mm jack plug to 3 pin XLR female cable

Getting Started

1. Using the 'Y' IEC cable, connect either IEC to the Ripple Light and the IRiS control box.
2. Using the supplied XLR cable, connect the 3 pin XLR on the control box, to the 'DMX in' on the bottom of the Ripple Light.
3. Connect the standard plug to a suitable mains outlet.
4. The unit will now illuminate and scroll through the standard IRiS colours before going out.
5. Now it's ready to use.
6. Decide which IRiS Talker you want to control the IRiS Ripple Light with then go to the Pairing section.

Instruction Manual

Pairing IRiS Talkers to the IRiS Ripple Light

This procedure is split into 2 sections, one for those who do not have an IRiS Master Pairer and for those who do.

Without an IRiS Master Pairer

Every IRiS Listener has a button on it called a pairing button. To get the IRiS Ripple Light to work with a product, first turn on the IRiS Ripple Light then decide which IRiS Talker you want to control it with – in this example we use the IRiS Qube but all work in the same manner.

Next find the pairing button on the bottom of the IRiS control box and press it, a red LED on the DMX control box will start to blink. You then need to activate the IRiS Qube within 5 seconds (in this case you would turn the Qube over). The IRiS Ripple Light will now change colour every time you turn the Qube if correctly paired, if it does not then repeat the above.

To put the unit into Calming mode, press the pair button on the bottom of the control box and do not activate any IRiS Talker, the unit now changes colour automatically.

With a IRiS Master Pairer

To get the IRiS Ripple Light to work with an IRiS Talker, first turn on the IRiS Ripple Light then decide which IRiS Talker you want to control it with – in this example we use the IRiS Qube but all work in the same manner. Then find the button on the IRiS Master Pairer that corresponds with the IRiS Ripple Light (usually identified by a white round numbered sticker on the Ripple Light, and press it. You then need to activate the IRiS Qube within 5 seconds (in this case you would turn the Qube over). The IRiS Ripple Light will now change colour every time you turn the Qube if correctly paired. If it does not, then repeat the above.

To put the unit into Calming mode. On the IRiS Master Pairer, press the number that corresponds to the IRiS Ripple Light, and do not activate any IRiS Talker, after 5 seconds the unit will change colour automatically.

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth. A non abrasive cleaning agent may be used for stubborn stains. Ensure no liquid enters the unit.

The unit has been designed for use by people with special needs however this does NOT mean it is unbreakable.

Troubleshooting

Note – There are a bank of 10 DIP switches one the Ripple Light. These must not be moved from the setting of 1, 4 and 10 ON, all others OFF, changing these will stop the IRiS box from controlling the Ripple Light.

Instruction Manual

Troubleshooting - cont

Q. The unit doesn't work.

A1. Is it switched on? If so,

A2. Has the unit scrolled through its colours? If so

A3. Has the unit been paired to an IRiS Talker, if so,

A4. Is the battery in the IRiS Talker fully charged, If so,

A5. Have you tried a different IRiS Talker, If so, please contact us.

Contact Details

For USA please email office@experia-usa.com

For Ireland please email support@experia-ireland.ie

For UK and rest of the world email support@experia-innovations.co.uk

Telephone: 0044 (0) 845 644 0977.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

QUESTIONS & IDEAS?

If you have an idea on how to improve this product or want to see your product idea realised, please email: ideas@experia-innovations.co.uk.

All ideas are presented to our OT, technical and finance department and if all procedures are passed we will contact you to discuss your idea further.

We can't promise to develop every product but if it's a great idea, we'll try!

Manufactured proudly in the UK by:

Experia, Acorn Phase 3, High Street, Grimethorpe, S72 7BD.



© Copyright 2017 Experia All rights reserved. Experia is a registered trademark