



M Clayton
26/09/2017
V1
010019

PREPARED
DATE
VER NO.
PRODUCT CODE

Instruction Manual

For

IRiS Fogger



experia
multisensory for everyone

Experia
Acorn Phase 3, High Street
Barnsley, South Yorkshire
S72 7BD, United Kingdom

T 0800 612 6077
Einfo@experia-innovations.co.uk
Wwww.experia-innovations.co.uk

Instruction Manual

Congratulations on the purchase of your IRiS Fogger!

The IRiS Fogger has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of switching learning and fun!

The IRiS Fogger offers endless opportunities to develop numerous skills including colour recognition, cause and effect, and many more.

The IRiS Fogger is an IRiS Listener and can be controlled by any number of IRiS Talkers.

****This unit gets hot so must be mounted out of reach****

Please ensure you read this Instruction Manual in full before operating the unit.

Heed all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

- IRiS Wirefree Compatible
- Ergonomic Design
- Uses water based fog fluid
- Durable
- Easy to use
- 3 Year Manufacturers Guarantee (Return to base)

Instruction Manual

Getting Started

Always ensure the fog fluid reservoir never runs dry as this can damage the fog machine

1. Switch on the unit and wait for the LED on the front of the control box to illuminate (about 5 minutes).
2. Now it's ready to use.
3. Decide which Talker you want to control the IRiS Shape Projector with then go to the Pairing section.

Pairing to IRiS Listeners

This procedure is split into 2 sections, one for those who do not have an IRiS Master Pairer and for those who do.

Without an IRiS Master Pairer

Every IRiS Listener has a button on it called a pairing button. To get the IRiS Fogger to work with a product, decide which IRiS Talker you want to control it with – in this example we use the IRiS Qube but all work in the same manner.

Next find the pairing button on the front of the IRiS Fog Control box and press it. You then need to activate the IRiS Qube within 5 seconds (in this case you would turn the Qube over). The IRiS Fogger will now emit smoke for various lengths of time, every time you turn the Qube if correctly paired. If it does not, then repeat the above.

With an IRiS Master Pairer

To get the IRiS Fogger to work with a product, first turn on the IRiS Fogger on allow to heat up (approx. 5 minutes), then decide which IRiS Talker you want to control it with – in this example we use the IRiS Qube but all work in the same manner. Then find the button on the IRiS Master Pairer that corresponds with it and press it. You then need to activate the IRiS Qube within 5 seconds (in this case you would turn the Qube over). The IRiS Fogger will now emit smoke for various lengths of time, every time you turn the Qube if correctly paired. If it does not, then repeat the above.

Instruction Manual

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth. A non-abrasive cleaning agent may be used for stubborn stains. Ensure no liquid enters the unit.

The unit has been designed for use by people with special needs however this does NOT mean it is unbreakable.

How to Fill The Fog Fluid Reservoir

WARNING – PLEASE ENSURE THE UNIT IS FULLY COOL BEFORE ATTEMPTING TO FILL RESERVOIR

1. Remove the lid from the reservoir on the top of the main unit.
2. Fill the reservoir with fog fluid. Ensure any spillages are wiped up immediately.
3. Replace the reservoir lid , ensuring the pipe is down to the bottom of the reservoir.

Troubleshooting

Q. The unit doesn't work.

A1. Is it switched on? If so, see 2

A2. Has the unit reached operating temperature (LED illuminated on control box)? If so, see 3

A3. Has the unit been paired to an IRiS Talker? If so, see 4

A4. Is the battery in the IRiS Talker fully charged? If so, see 5

A5. Have you tried a different IRiS Talker? If so, please contact us.

Instruction Manual

Contact Details

For USA please email office@experia-usa.com

For Ireland please email support@experia-ireland.ie

For UK and rest of the world email support@experia-innovations.co.uk

Telephone: 0044 (0) 845 644 0977.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

QUESTIONS & IDEAS?

If you have an idea on how to improve this product or want to see your product idea realised, please email: ideas@experia-innovations.co.uk.

All ideas are presented to our OT, technical and finance department and if all procedures are passed we will contact you to discuss your idea further.

We can't promise to develop every product but if it's a great idea, we'll try!

Manufactured proudly in the UK by:

Experia, Acorn Phase 3, High Street, Grimethorpe, S72 7BD.



© Copyright 2017 Experia All rights reserved. Experia is a registered trademark