



M Clayton
26/09/2017
V1
010029

PREPARED
DATE
VER NO.
PRODUCT CODE

Instruction Manual

For

IRiS Jet Stream



experia
multisensory for everyone

Experia
Acorn Phase 3, High Street
Barnsley, South Yorkshire
S72 7BD, United Kingdom

T 0800 612 6077
Einfo@experia-innovations.co.uk
Wwww.experia-innovations.co.uk

Instruction Manual

Congratulations on purchasing an IRiS Jet Stream!

Please ensure you read this Instruction Manual in full before operating the unit.

Heed all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

- The fan can be controlled by any IRiS Talker to produce anything from a gentle breeze to a howling gale.
- This is a great product that provides unusual feedback - particularly useful for those with visual impairments.
- The IRiS Jet Stream is a wall or ceiling mounted fan allowing users to safely get closer to the breeze generated and aids the development of cause and effect skills.
- It can be used with any IRiS Talker to change the speed of the fan to enhance the experience.
- Operates on mains voltage.
- Easy to use.
- 3 Year Manufacturers Guarantee (Return to base).
- An IRiS Talker is required to use with this product.

Getting Started

1. Connect the IRiS Jet Stream control box to the remote XLR connection on the back of the fan.
2. Connect the IEC lead (supplied) to the IEC connector on the back of the fan.
3. Connect the stand mains plug to a suitable mains outlet.
4. Switch on the power, the fan will speed up and then stop.
5. Now it's ready to use.
6. Decide which IRiS Talker you want to control the IRiS Jet Stream then go to the pairing section.

Instruction Manual

Pairing to IRiS Talkers

This procedure is split into 2 sections, one for those who do not have an IRiS Master Pairer and for those who do.

Without an IRiS Master Pairer

Every IRiS Listener has a button on it called a pairing button. To get the IRiS Jet Stream to work with a product, first turn on the IRiS Jet Stream then decide which IRiS Talker you want to control it with – in this example we use the IRiS Qube but all work in the same manner.

Next find the pairing button on the top of the control box and press it for 1 second. You then need to activate the IRiS Qube within 5 seconds (in this case you would turn the Qube over). The IRiS Jet Stream will now change speed every time you turn the Qube if correctly paired. If it does not, then repeat the above.

With an IRiS Master Pairer

To get the IRiS Jet Stream to work with a product, first turn on the IRiS Jet Stream then decide which IRiS Talker you want to control it with – in this example we use the IRiS Qube but all work in the same manner. Then find the button on the IRiS Master Pairer that corresponds with it and press it. You then need to activate the IRiS Qube within 5 seconds (in this case you would turn the Qube over). The IRiS Jet Stream will now change colour every time you turn the Qube if correctly paired. If it does not, then repeat the above.

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth. A nonabrasive cleaning agent may be used for stubborn stains. Ensure no liquid enters the unit.

The unit has been designed for use by people with special needs however this does NOT mean it is unbreakable.

Troubleshooting

Q. The unit doesn't work.

A1. Is it switched on? If so, see A2

A2. Is the IRiS Control box connected to the remote connection on the fan? If so, see A3

A3. Has the unit come on for a few seconds? If so, see A4

A4. Has the unit been paired to an IRiS Talker? If so, see A5

A5. Is the battery in the IRiS Talker fully charged? If so, see A6

A6. Have you tried a different IRiS Talker? If so, please contact us.

Instruction Manual

Contact Details

For USA please email office@experia-usa.com

For Ireland please email support@experia-ireland.ie

For UK and rest of the world email support@experia-innovations.co.uk

Telephone: 0044 (0) 845 644 0977.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

QUESTIONS & IDEAS?

If you have an idea on how to improve this product or want to see your product idea realised, please email: ideas@experia-innovations.co.uk.

All ideas are presented to our OT, technical and finance department and if all procedures are passed we will contact you to discuss your idea further.

We can't promise to develop every product but if it's a great idea, we'll try!

Manufactured proudly in the UK by:

Experia, Acorn Phase 3, High Street, Grimethorpe, S72 7BD.



© Copyright 2017 Experia All rights reserved. Experia is a registered trademark