















**Deluxe Soundstar** 

For



Experia Acorn Phase 3, High Street Barnsley, South Yorkshire S72 7BD, United Kingdom

**Congratulations** on the purchase of a Deluxe Soundstar.

The Deluxe Soundstar has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of interactive learning and fun!

The Deluxe Soundstar offers endless opportunities to develop numerous skills including colour recognition, cause and effect, motor skills and many more!

Please ensure you read this Instruction Manual in full before operating the unit.

### **EXPERIA GENERAL WARNINGS AND CAUTIONS**

PLEASE READ THE INSTRUCTIONS WITHIN THIS MANUAL CAREFULLY BEFORE INSTALLING OR OPERATING THIS PRODUCT. Read all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

#### **Features**

- 13 Automatic Switch Modes
- 13 Sound Activated Switch Modes
- LED Driven no lamp to change
- Silent Running
- Environmentally friendly 3 x as efficient as lamp based products
- Designed to meet and exceed CE standard
- Easy to clean
- Rugged, built to last
- 3 Year Warranty
- Low Maintenance
- Easy to Use
- External Microphone
- Designed for all ages and abilities

### **Pack contents**

- 1 x Deluxe Soundstar
- 1 x Mains lead
- 1 x Microphone
- 1 x Product Manual
- 1 x Installation Manual
- 1 x Wall fixing kit

### **Unpacking your Deluxe Soundstar**

Check packaging for signs of damage before opening.

Do not use sharp objects during unpacking.

Check the parts received against the Pack Contents. Read the product manual before use.

It is recommended that any wall mounted product is installed by a competent person and following the installation manual.

### **Quick Start Guide**

Once your Deluxe Soundstar has been installed;

- 1. Switch on the mains power.
- 2. Wait a few seconds for the self-check sequence.
- 3. Press the on-off button on the display panel.
- 4. Wait a moment.
- 5. Once the display shows the mode name "Ring 1", select the mode you wish to use.
- 6. Enjoy the Deluxe Soundstar!

### **Control Panel Explained**

- · On/Off: turns the unit on or off.
- · Speed: adjusts the speed of the LED pattern.
- · Sensitivity: adjusts the pattern response from the microphone when in sound active mode.
- · Fade: adjusts the length of time the LEDs illuminate after being triggered.
- · Mode: scroll through the various modes of operation.
- $\cdot$  Select: switches between auto-colours and the colour wheel selected colour.
- · Microphone: Used for connecting the external microphone
- · Colour Wheel: user selectable shades of colour.

### **Operating Instructions**

Switching on the Deluxe Soundstar

- 1. Plug in and switch on at the mains supply. The Deluxe Soundstar will now self-check.
- 2. Once the self-check has occurred the Deluxe Soundstar goes into sleep mode.
- 3. Press the control panel on-off button to wake up the Deluxe Soundstar which will now boot-up.
- 4. Once the Deluxe Soundstar displays the mode 'Ring 1' it is ready for use.
- 5. When the microphone is not connected the unit will run through the selected mode automatically.
- 6. To use the Deluxe Soundstar with the microphone, simply connect the jack plug to the microphone socket on the front panel. Every mode will now be sound responsive.

### **Deluxe Soundstar modes of operation**

The modes of operation listed below are variably affected by adjusting the speed and fade settings. If a mode selected isn't working well for the user then make some changes and try again. The LED colour can be user selected by simply touching the colour wheel and watching the circle of lit LEDs in the middle of the touch screen area until the desired colour has been achieved. Some of the modes can behave differently if the sensitivity is turned up too much, turn it down a little to correct this.

Ring 1

Ring 2

Scan

Clock

**Explosion** 

Wheel 1

Wheel 2

Wings

Star 1

Star 2

Spiral Out

Spiral In

Twinkle

### **Trouble Shooting**

- Q1. My Deluxe Soundstar won't switch on
- A1. Have you switched it on at the mains supply and then pressed the on/off button? If so, has the fuse in the plug top been checked? If so, has the mains socket been checked? If so, please contact support.
- Q2. My Deluxe Soundstar doesn't respond to the microphone
- A2. Is the microphone jack plug fully inserted into the microphone socket? If so, is the microphone switched on? If so, is the sensitivity control turned fully clockwise? If so, please contact support.

### **Contact Details**

For USA please email <a href="mailto:support@experia-usa.com">support@experia-usa.com</a>

For UK and rest of the world email <a href="mailto:support@experia-innovations.co.uk">support@experia-innovations.co.uk</a>

Telephone: 0044 (0) 845 644 0977.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

### **QUESTIONS & IDEAS?**

If you have an idea on how to improve this product or want to see your product idea realised, please email: <a href="mailto:ideas@experia-innovations.co.uk">ideas@experia-innovations.co.uk</a>.

All ideas are presented to our OT, technical and finance department and if all procedures are passed we will contact you to discuss your idea further.

We can't promise to develop every product but if it's a great idea, we'll try!

### Manufactured proudly in the UK by:

Experia, Acorn Phase 3, High Street, Grimethorpe, S72 7BD.







© Copyright 2017 Experia All rights reserved. Experia is a registered trademark